

図 1





図 2




図 3



0994943-112801
T08211-E4646660

图 4



00004943.112801

図 5



090*****)

図 6

(A)




Figure 6(A) is a screenshot of a mobile device screen. At the top left, there is a signal strength indicator (three bars) and a battery level indicator (four bars). The text "名前を登録してください" (Please register your name) is displayed in the center. Below the text is a text input field containing the name "やまだたろ" (Yamada Taro) followed by a black square cursor.

(B)




Figure 6(B) is a screenshot of a mobile device screen, similar to (A). It shows the same signal and battery indicators at the top. The text "名前を登録してください" (Please register your name) is displayed in the center. Below the text is a text input field containing the name "やまだたろう" (Yamada Tarou).

723-1221, 3464660

図 7




FIG. 7

図8





FIG. 8

図 9



0994943-12201

图 10






図 1 1




0904943-11201
 703217 E464660

図 1 2



00000000h

図 1 3



Sheet 12 of 39

図14

d07	d06	d05	d04	d03	d02	d01	d00
-	-	LCNT5	LCNT4	LCNT3	LCNT2	LCNT1	LCNT0

LCNT0:モード選択フラグ

0:電話

1:ゲーム

LCNT1:2値画像出力制御フラグ

0:中止

1:出力

LCNT2:カラー画像フレンディング制御フラグ

0:ノーマル

1:フレンディング

LCNT4,3:カラー画像トーン制御フラグ

00:中止

01:トーンダウン

10:等倍トーン

11:トーンアップ

LCNT5:LCD表示オンオフフラグ

0:表示オフ

1:表示オン

0904943-11304
T0827F-E4646660

図15

ゲームキーレジスタ1

d7	d6	d5	d4	d3	d2	d1	d0
K7	K6	K5	K4	K3	K2	K1	K0

K7:SELECTキー
K6:STARTキー
K5:十字キー(右)
K4:十字キー(左)
K3:十字キー(下)
K2:十字キー(上)
K1:Bボタン
K0:Aボタン

ゲームキーレジスタ2

d7	d6	d5	d4	d3	d2	d1	d0
KI7	KI6	KI5	KI4	KI3	KI2	KI1	KI0

KI7:SELECTキー
KI6:STARTキー
KI5:十字キー(右)
KI4:十字キー(左)
KI3:十字キー(下)
KI2:十字キー(上)
KI1:Bボタン
KI0:Aボタン

ゲームキーレジスタ3

d7	d6	d5	d4	d3	d2	d1	d0
KO7	KO6	KO5	KO4	KO3	KO2	KO1	KO0

KO7:SELECTキー
KO6:STARTキー
KO5:十字キー(右)
KO4:十字キー(左)
KO3:十字キー(下)
KO2:十字キー(上)
KO1:Bボタン
KO0:Aボタン

Foot" E4646660

図 1 6




図 1 7




FIG. 16

FIG 18





FIG 19



723-1221 "E464660"

図 2 0





図 2 1



09094943-112301
T032T E464660

図 2 2




FIG. 22

図 2 3






FIG. 23

図 2 4




090494-1201
T082T E46660

図 25




00004913 11201
T0821T E4646660

図 26




0994943.12301
T082T E466660

図 27




723-1221 E464666

図 28




Sheet 24 of 39

図 29




09994943-112301
T03211 E4646660

図 3 0



703211 E4646660

図 3 1



0994943-12201
T022T" E464660

図 3 2

0000000000101001 : キー割当依頼
0000000000001010 : 「#」を示すキーコード
0000000010000000 : セレクを示す機能情報
0000000000001011 : 「*」を示すキーコード
0000000001000000 : スタートを示す機能情報
0000000000000000 : エンドコード


図 3 3

34a

キー	キーコード	機能情報
#	1010	セレク
*	1011	スタート
0		
1		
2		
:	:	:
9		

TEST SHEET 28 of 39

図 3 4



103211 464660

図 3 5






FIG. 35

図 3 6

(A)



(B)




(C)




723-1221 "OKADA" 454560

図 3 7

(A)



(B)



(C)






FIG. 37

図 3 8


(A)



(B)




(C)



TOP SECRET

図 39



FOOTPRINT 46660

図 40





FIG. 40

図 4 1



TEST-CH6660

図 4 2





FIG. 42

図 4 3



Sheet 38 of 39

図 4 4




図 4 5

